

ONE YEAR WARRANTY

Inergy warrants this power supply to be free from defects in materials and workmanship under normal use for a period of one (1) year from the date of purchase, as evidenced by the purchase receipt.

During the warranty period Inergy shall repair or replace the power supply if defective. If replaced, the replacement shall be with a product of equal or greater value at sole discretion of Inergy. This warranty is limited to the purchaser and is not transferable. This warranty is only valid when the warranty registration is filled out in full and mailed, faxed, or emailed to Inergy within 90 days from the date of purchase.

This warranty does not cover cosmetic damage or damage due to acts of God, accident, misuse, abuse, negligence, commercial use, or modification of, or to any part of the product. Opening the product casing will void warranty. This warranty does not cover damage due to improper operation or maintenance, connection to improper voltage supply, or attempted repair by anyone other than a facility authorized by Inergy to service the product.

Name: _____


Address: _____

City: _____ **State:** _____

Email: _____ **Telephone:** _____



4978 Rainbow Ln.
Chubbuck, ID 83202
Email: info@inergyhome.com
Fax: 208.232.5925
www.inergyhome.com



User Manual Inergy 600

INSTRUCTION MANUAL 600W POWER SUPPLY

This power supply is designed for all major brand cellular phones, laptop computers, digital portables such as video cameras, digital cameras, portable gaming devices, and other handheld electronics.

Before You Begin:

Only use this device after reading all the instructions.

It's normal for the power supply to get warm to the touch when in use, avoid leaving power supply in prolonged sunlight or next to heat sensitive materials.

Safety Precautions:

- Do not use with any appliance with dangerous voltage warning.
- Do not use with over 16V DC input.
- Do not go over the inverter wattage.
- Never block ventilation to the power supply.
- Do not use power supply near any open flame, flammable liquid, or gases.
- Do not expose to liquid or moisture or humidity.
- Do not attempt to disassemble.
- Do not handle with wet hands.
- Do not put metal fragments (eg. such as wire) inside.
- Keep out of reach of children.

Technical Specifications

Input voltage range	11-15VDC
Output rated power	400W Capacity/600W Inverter
Output voltage and frequency	100-120V/60Hz
Output voltage for USB ports	Top: 2.1A Bottom: 1A
Output Cigarette lighter socket	15A
Protections	Short circuit, overload, over temperature, low battery voltage, over battery voltage
Over voltage shutdown	DC15V-16V
Low voltage shutdown	DC10V-10.5V

Operation Guide:

To charge, plug in charger to charge input
Red charge indicator will light up.

To Use: turn on power switch.

Battery status indicator shows the battery power.

Remove USB adaptor to use cigarette lighter socket.

Connect to 110VAC outlets just as you would in your home.

Use the 12VDC front connector for 5A max power.

Note: DC outlets are live when unit is on or off.

USB ADAPTOR TO FIT INTO
CIGARETTE LIGHTER SOCKET

USB 2.1A Top Connector
USB 1A Bottom Connector

